

**Installation Instructions**  
**Billet Brake Line Clamp**  
**GYT-1P818-15-00**  
**05-Up YZ/YZF/WR**

Please read and understand these instructions completely before installation to avoid injury to yourself or damage to the motorcycle and/or accessory.

Yamaha Recommends installation by the dealer or a qualified mechanic.

**Dealer:** These instructions contain important information for future reference; please give them to the customer.

**1. Parts List:**

1	Brake Line Clamp	Billet Brake Line Clamp	1
2	Flange Head Bolt	M6 x 10mm Bolt	2



**2. Preparation:**

- a) Place motorcycle on a secure stand.
- b) Clean all mounting surfaces before beginning installation.

**3. Installation:**

**Note: Use Loctite 242 Threadlocker on each fastener to prevent loosening while riding.**

- a) Remove stock brake line clamp.
- b) Push the two steel inserts for the stock brake line clamp out of the fork guard. (use 8mm hex wrench or similar diameter tool)
- c) Press one side of the clamp (item 1) into the fork guard.
- d) Place brake line in the clamp and put second side of clamp around brake line.
- e) Insert bolts (item2) and tighten to 12Nm (9 ft-lbs).

**4. Maintenance:**

Periodically check torque on all hardware. If loose hardware is found, remove hardware, clean off old Loctite, re-apply fresh Loctite and re-torque to specification.

**5. Care and Cleaning:**

Wash using a mild soap and water solution and soft cloth.

**6. Customer Service:**

For further information see your Yamaha dealer.