



Installation Instructions Clutch Kit-YZ450F GYT-5TA56-30-00

Please read and understand these instructions completely before installation to avoid any possible injury to yourself or damage to your motorcycle and/or accessory.

Dealer:

These instructions contain important information for future reference and must be given to the customer.

1. Parts List:

ITEM	PART NAME	DESCRIPTION	QTY
1	Push Lever	(For 2003 model only)	1
2	Oil Seal	(For 2003 model only)	1
3	Seat Plate	Flat Ring	1
4	Clutch Boss Spring	Beveled Ring	1
5	Friction Plate 2	Inside diameter 128mm (5.0 in.)	1
6	Clutch Plate	Steel, with internal teeth	8
7	Friction Plate 1	Inside diameter 119mm (4.7 in.)	8

Note: If you are not experienced with this type of installation please see your Yamaha dealer to have this kit installed.

2. Removal and Installation:

- a) Follow the steps outlined in service manual YZ450FR (Yamaha part number LIT-11626-16-38).
- b) The stock push lever will be replaced with the supplied Push Lever, Item 1 (For 2003 models only). **Caution:** Be careful not to damage Oil Seal, Item 2 at installation
- c) When installing the new plates from your kit, observe the following sequence, starting from the inside.
Item 3 - Seat Plate
Item 4 - Clutch Boss Spring (the outside face is stamped on the part)
Item 5 - Friction Plate 2 (larger inside diameter)
Item 6 - Clutch Plate (internal teeth)
Item 7 - Friction Plate 1 (smaller inside diameter)
Continue alternating the remaining Clutch Plates, item 6 with the Friction Plates item 7.

3. Maintenance:

- a) Refer to owner's manual.

4. Customer Service:

- a) For further information see your Yamaha dealer.