

## INSTALLATION INSTRUCTIONS

DESCRIPTION: Rear Brush Guard Kit

PART NUMBER: B4F-F85E0-V0

MODEL: Grizzly 700, Kodiak 700



### **⚠ WARNING**

Please read and understand these instructions completely before installation to avoid possible injury, or damage to the accessory or vehicle.

### **NOTICE:**

This installation requires a torque wrench and should be performed by an authorized Yamaha dealer or other qualified technician.

### **WARRANTY INFORMATION:**

Genuine Yamaha Accessories are covered by a one-year limited warranty against defects in material or workmanship. Labor for replacement of defective components is not covered. See your Yamaha dealer for a copy of the warranty statement.


### **DEALER OR INSTALLER:**


These instructions contain important information for future reference and *must* be given to the customer.

### **PARTS LIST:**

No.	Part Number	Description	Qty
--	B4F-F85E0-V0	Rear Brush Guard Kit	--
①	*	Rear Brush Guard	1

\* Part supplied with kit only and not available separately.





#### PREPARATION:

- Place the vehicle on a secure and level surface.
- Set the parking brake.
- Clean the mount surfaces before starting installation.

#### INSTALLATION:

**Note:** Grizzly and Kodiak models have slightly different lower mount points. They are described and shown in step 3 below.

1. Working from the rear of the ATV, remove the four bolts, 2 M8 on the upper mount and 2 M10 on the lower mount. These stock bolts hold the stock rack supports to the frame (see Fig. 1). Retain the bolts for reuse. The stock rack supports will not be reused.
2. Install 2 M8 bolts to the Brush Guard and thread them through the mounts on upper rear rack. Leave these hand tight.

#### On the Grizzly 700

3. Install 2 M10 bolts to the **lower mount holes** on the flange at the base of the Brush Guard. Thread into the mounts on the frame and torque to 60Nm (6.0 m-kgf, 44.3 ft-lbf) as shown in Fig. 3.

#### On the Kodiak 700

3. Install 2 stock M10 bolts to the **upper mount holes** on the flange at the base of the Brush Guard. Thread into the mounts on the frame and torque to 60Nm (6.0 m-kgf, 44.3 ft-lbf) as shown in Fig. 3.

4. Torque the 2 M8 bolts installed in step 2 to 34 Nm (3.4 m-kgf, 25.0 ft-lbf).

#### MAINTENANCE:

Periodically, check torque on all hardware. If loose hardware is found, re-torque to specification.

#### CARE AND CLEANING:

Clean painted metal parts with a clean soft cloth and mild soap and water. Rinse and dry.

#### CUSTOMER SERVICE:

For further information see your Yamaha dealer.

**ESTIMATED TIME TO INSTALL: 0.5 HRS**

