

## INSTALLATION INSTRUCTIONS

DESCRIPTION: Front Skid Plate Kit

PART NUMBER: B4J-F84N0-V0

MODEL: 2021+ Wolverine RMax2 and RMax4



### **⚠ WARNING**

Please read and understand these instructions completely before installation to avoid possible injury, or damage to the accessory or vehicle.

### **NOTICE:**

Installation of this kit requires a torque wrench and should be performed by an authorized Yamaha dealer or a qualified mechanic.

### **WARRANTY INFORMATION:**

In the United States, see your Yamaha dealer for a copy of the Yamaha Genuine parts and Accessories Limited Warranty.


### **DEALER OR INSTALLER:**

These instructions contain important information for future reference and *must* be given to the customer.


### **PARTS LIST:**

No.	Part Number	Description	Qty
--	B4J-F84N0-V0	FRONT SKID PLATE KIT	
①	-	FRONT SKID PLATE	1
②	-	REINFORCEMENT PLATE	1
③	B4J-E2615-V0	M8x25 HEX DRIVE, SS	4
④	B4J-E261D-V0	M8, SPRING NUT W/DISTORTED THREAD	4

\* Part supplied with kit only and not available separately.



**Fig. 1**




**PREPARATION:**

- Place the vehicle on a secure and level surface. Set the parking brake.
- Clean the mount surfaces before beginning installation.
- **Note:** If the B4J-F84P0-V0 Skid Plate Kit will be installed, then this Front Skid Plate kit needs to be installed first.

**INSTALLATION:**


1. Remove the six bolts that hold the stock skid plate in place. Retain all the stock bolts and discard the shoulder washers. (Fig. 1)
2. Insert the four (4) Spring nuts into the sides of the (2) reinforcement plate with the threaded side towards the back. (Fig. 3)
3. Insert the top two stock button head bolts through the (2) Reinforcement Plate into the frame and torque to 10 Nm (1.0 kg-m or 7.3 lb-ft).
4. Align and install the (1) Front Skid Plate over the (2) Reinforcement Plate with the rest of the stock hardware. Torque to 10 Nm (1.0 kg-m or 7.3 lb-ft). (Fig. 2)
5. Install the four (3) M8x25 Hex Drive bolts into the (1) Front Skid Plate and into the (2) Reinforcement Plate. Torque to 8 Nm (0.8 kg-m or 5.9 lb-ft). (Fig. 4)

**Fig. 2**




Step: 4 **Tip:** Align the front of the Skid Plate first.

**Fig. 3**



**Fig. 4**



**MAINTENANCE:**

Periodically, check torque on all hardware. If loose hardware is found, re-torque to specification.

**CARE AND CLEANING:**

Clean painted metal parts with a clean soft cloth and mild soap and water solution. Rinse and dry.

**CUSTOMER SERVICE:**

For further information see your Yamaha dealer.

**ESTIMATED TIME TO INSTALL: 0.5 HRS.**